



Axle Service Manual 6000/7000 Disc Brake

Updated : October 2020
80259 Rev C



Whilst every effort has been made to ensure that this manual is as accurate as possible, Granning cannot be held responsible for any omissions or errors. We reserve the right to alter specification without prior notice.

Revision: Oct 2020

Granning are one of the Europe's primary Air Suspension and Axle Manufacturers. We are experts in road vehicle axles, brakes and suspensions. Operators throughout the world are reaping the benefits of our road friendly air suspensions and high quality non driven axles.

We hope you get many years of service from your Granning axle and in order to ensure you do, please follow the instructions contained in this manual.

Please record the below information as you may require it when identifying service components.


Axle information record:

Date Fitted:

Chassis Number:

Axle Model Code:

Axle Serial Number:



www.granningaxles.ie

80259 REV C Oct 2020 Page | 1

Ireland

T. +353 (0) 45 897 553
F. +353 (0) 45 848 638

UK

T. +44 (0) 1925 817 689
F. +44 (0) 1925 817 153

NI

T. +44 (0) 2890 740 055
F. +44 (0) 2890 752 718


Poland

T. +48 (0) 29 753 1616
F. +48 (0) 29 753 1604



Contents

Health & Safety	3
Axle Installation	4
Wheel Fastening	8
Servicing Of Axle	9
Fitting Of Components	11
Trouble Shooting	25



www.granningaxles.ie

80259 REV C Oct 2020 Page | 2

Ireland

T. +353 (0) 45 897 553
F. +353 (0) 45 848 638

UK

T. +44 (0) 1925 817 689
F. +44 (0) 1925 817 153

NI

T. +44 (0) 2890 740 055
F. +44 (0) 2890 752 718

Poland

T. +48 (0) 29 753 1616
F. +48 (0) 29 753 1604

Health and Safety Guidelines

Do ✓


- ALWAYS use genuine GRANNING components. ✓
- ALWAYS use suitable tools for the job. ✓
- ALWAYS work in good, safe working conditions. ✓
- ALWAYS use safety equipment. ✓
- Always follow your own Health and Safety systems. ✓



Don't ✗

- NEVER work under an unproped body or axle. ✗
- NEVER leave an un-proped body or axle unattended. ✗
- NEVER work without supervision. ✗

All Granning axles employ Asbestos Free friction material, however, when servicing a used axle, take care Asbestos might be present in brake linings. Always assume that Asbestos is present and take appropriate steps to ensure safety of all involved



Axle Serial Badge Information

Website address to download additional axle information such as TUV cert and BOM

Axle Brake Size



Axle Series Name

TUV Cert Number



Unique axle serial number for traceability

Axle brake testing information

Read this section before welding the axle saddles

Beam Stresses

Granning Axle beams are manufactured from high tensile, hot rolled hollow tube. In service these beams are subjected to combined bending and torsional stresses. Maximum combined stresses occur along the top and lower surface of the beam. The minimum stresses occur along the front and rear centre line, called the neutral axis. It is an accepted fact that welding steel causes a heat effected zone which embrittles the metal in that area. Therefore, any welding on the axle beam must always be away from the high stress lines and near to the neutral axis.



Effects of Beam Welding



When a weld is made on the beam, it creates in effect an area of extreme localised heat treatment. The heat generated by the welding process will cause the beam material, within the immediate vicinity of the weld, to become hardened. This results in a small area of brittleness replacing the required property of ductility. It can be seen that should an area of localised hardening appear at either point of maximum stress, the strength of the beam could seriously be affected. Therefore any welding must be in the neutral zone, ie not in top or lower 100 degrees.

Welding precautions

- Connect the earth directly to the work piece. Not to suspension spring.
- NEVER weld to the upper or lower surfaces of the axle.
- Confine welds to axle surfaces not exceeding 40° above or below the horizontal.
- Remove oil and paint from areas to be welded.
- As far as possible, try to avoid overheating the axle.
- Protect the spring Beam / Leaf and rubber components from weld splatter.
- Welds must contain NO voids, craters, inclusions or cracks.
- When ambient conditions are below 20°C, preheat the weld areas.

Locating axle seat/saddle before welding

Ensure axle beam sits correctly in the seat/saddle. The below diagram is exaggerated but shows the bottom of the axle beam should make contact with the axle seat. A gap between the axle seat and beam can cause excessive weld stress and crack the axle beam.




Saddle / Seat welding

- Set saddle centres to the given dimension.
- Ensure that the axle tube and saddle cup are clean.
- Centre axle between the saddles.
- Locate camshaft/brake position ensuring correct rotation and position.
- Set saddle spring surfaces parallel to one another.
- Once all of the above has been assured and re-checked, weld saddles as below.

Although it is possible to make a 10 mm fillet weld in one pass, we recommend that this be done in **three passes**. The order of which are shown in the close up below. Make second and third runs before previous welds are cool, de-scaling first.

The weld is to be in direction towards the axle centre, it is to start on outer side and be completed on inboard side of saddle.





Axle Tracking

All Granning axles are constructed so that the toe in / out is less than 2 mm / metre. Responsibility for proper axle alignment lies with the axle installer. The Granning Axle Range includes Trailer axles and Truck axles.


Trailer axles are aligned (tracked) from the trailer king pin to fixed points on the front axle. Following axles are tracked from the front axle.

Truck Axles should be aligned parallel to the DRIVE axle.





Tracking of truck axles




Tracking of trailer axles

Wheel fasteners

It is vital that operators and manufacturers ensure that the correct type of wheel cones and nuts are fitted to specified bolts, before torqueing to full setting.


The below diagrams show the six main nut and bolt configurations.

Wheel Rims and Fasteners of different standards must not be interchanged or mixed in any combination.




Mating surfaces between Hubs and Wheel Rims should be primer painted only. Thick gloss will result in loss of torque.

	Ft.Lb	N.m
Wheel nuts - BSF / DIN	369 - 395	500 - 535
Wheel nuts - ISO	442 - 465	600 - 630
Wheel nuts - Alloy	442 - 465	600 - 630





To achieve correct tension in each of the wheel locating bolts, and thus optimum wheel security, Tighten wheel nuts in the order shown below.



Axle servicing

In order to achieve maximum performance from your Granning axle it requires regular servicing outlined below.

Service intervals depend on operating conditions and are best decided by the Operators Fleet Engineer. The following guide lines are for axles used for general road haulage. It's recommended that records of this servicing are kept for future reference.

Note: local legislative regulations should always be followed.

On Initial Receipt >

Check all nuts, etc. for recommended torque. It is strongly recommended that wheel nut torque is checked every 7 days or 1000 km, whichever is the sooner.

First 300 miles (500 km) >


Check all wheel nuts daily for first week, due to seating effects. It is suggested that the hubs are checked for end-float, again due to seating effects. Lubricate all grease points, using Lithium soap-based EP2 grease.

At 3,000 miles (5,000 km) >

Check same as first 300 miles (500 km). Check wear pattern of brake linings, if not satisfactory, make correct adjustment. Check hubs for end-float. Reset adjustment nut if necessary.

At 10,000 miles (15,000 km) and every 10,000 miles thereafter >

Lubricate all grease points. Check hubs for bearing end-float. Adjust as necessary. Lubricate slack adjusters. Check brake linings for wear.






At 30,000 miles (50,000 km) and every 30,000 miles thereafter >

Remove hubs, check brake linings for wear. Completely clean out grease from hub. Repack, using fresh grease. Check grease seals for signs of wear, replace if necessary. Reset bearing adjustment nuts to give bearing end-float.


Bearing types – 6000 & 7000 series

The 6000 & 7000 series axles come with three different bearing configurations. Images in the following sections will help match the hub removal and brake disc procedures to the particular version. The three versions of bearing configuration are as follows:


- UniPac




- Twin bearing



- Offset hub with standard taper bearing



Procedures for each version have differences so it is important that the correct method is followed






Bearing Lubrication

The bearings used in Granning axles are of the finest materials, and produced to exacting standards. They are selected to give the user considerable service life. To protect this longevity, the following procedure is recommended when servicing is required:

- a) Immerse cups and cones in a suitable cleaning solution. After soaking, agitate bearings around in fluid to flush out any old residue grease. Never spin a bearing, this could cause the rollers to skid, thus damaging the highly finished internal surfaces of the bearing.
- b) When clean, thoroughly drain and dry, preferably in warm air at around 65 - 80°C.
- c) The bearing must be now checked for any signs of corrosion, discolouring, pitting or flaking. Should there be any doubts as to the condition of the bearing, replacement is strongly advised.
- d) If the bearing is to be refitted immediately, ensure the rollers are fully prepacked with lubricant (see recommended lubricants) before fitment. Alternatively, immerse the bearing in rust-preventative oil, wrap in wax paper, and box for storage.

Recommended lubricants

Manufacturer	Recommended	Alternative
Shell	Shell Gadus S3 V220C 2	Shell Retinax 'LX2'
Mobile	Mobile Grease H.P. 222	Mobile Grease H.P.
Castrol	Castrol LMX	Spheerol A.P.T.Z.
Texaco	Hytex EP2	
Esso	Unirex EP2	
BP	Energrease LC2	




Bearing lubrication – Twin bearing & Standard setup

Apply grease to these areas. It is important not to overfill the hub with grease!

Hub: 400 grams

Hub Cap: Small amount


Care: Greasing at high pressure may cause damage to the seals



Note:- If sealed for life bearings (UNIPAC) are fitted, do not tamper with or attempt to service. Any tampering with the bearing may drastically reduce the service life of the bearing and hubs, as well as invalidate the warranty. The only action required for sealed for life bearings is the addition of anti fretting lubricant onto the spindle prior to any reassembly. Timkin recommend 'Optimol White T', or 'Copperslip' as an alternative.

RECOMMENDED LUBRICANTS

MANUFACTURER	RECOMMENDED	ALTERNATIVE
Shell	Shell Retinax 'LX2'	Shell Retinax 'LX'
Mobil	Mobil Grease H. P. 222	Mobil Grease H. P.
Castrol	Castrol LMX	Spheerol A. P. T. Z.
Texaco	Hytex EP2	
Esso	Unirex EP2	
BP	Energrease LC2	




UniPac version: Changing hub & Brake disc change

Tools needed


Socket for carrier bolt, 27mm Across the Flats 6 sided

Socket for hub cap bolt, 13mm Across the Flats 6 sided


Allen key for locking screw, 6mm Across the Flats




In order to remove the hub and disc assembly, the caliper and carrier must be removed first




Undo and remove the carrier mounting bolts. Be aware the caliper assembly is heavy



Hub cap is removed by removing the eight retaining bolts




Undo and remove the locking screws







Remove the locknut




Remove the lock washer



The hub and disc assembly can be removed



The disc can be separated from the hub by removing the disc mounting bolts




Offset hub version: Changing hub & Brake disc change


Tools needed

Socket for locknut, 82.5mm Across the Flats 8 sided

Socket for adjusting nut, 96.6mm Across the Flats 8 sided



In order to remove the hub and disc assembly, the caliper and carrier must be removed first




Undo and remove the carrier mounting bolts. Be aware the caliper assembly is heavy



Hub cap is removed by removing the six retaining bolts



Straighten locking tab, then undo and remove locknut






Remove the tab washer




Remove the lock washer


The adjusting nut can then be unscrewed but care must be taken that the outer bearing does not drop out. Any dirt or damage to the bearings and grease can compromise the bearing life so ensure any grease is not exposed to dirt and parts are protected.



The hub and disc assembly can be removed



The disc can be separated from the hub by removing the disc mounting bolts




End float procedure Offset Hub

The offset hubs are fitted with two rows of tapered roller bearings. To protect normal bearing life, these bearings must not be subjected to preload during assembly and service.

The correct method of setting end float is as follows:

- Fit the adjusting nut and torque to 373 Nm.
- Rotate the brake drum 4 times and re-torque to 373Nm.
- Loosen the adjusting nut by one full revolution.
- Torque the adjusting nut to 102Nm.
- Back off (Loosen) the adjusting nut 1 to 1.5 flats.
- Fit the lock washer so the dowel pin of the adjusting nut slides into one of the holes of the washer. If necessary flip the washer to achieve this alignment, or loosen half a hole.
- Fit the lock nut and torque it to 373Nm.
- Fold down two of the tabs on the lock washer, one at 12 o clock and one 3 o clock.
- Rotate the brake drum 4 times to test the functionality of the brakes.
- Manually rotate the camshaft and simultaneously rotate the drum to check.
- Clean the surface area of the end of the spindle.
- The above procedure is used to set the end float to be between 0.0254mm - 0.1016mm (1 - 4 thousandth inch). Ideally this should be confirmed using a dial gauge.
- Apply a small amount of grease to spindle end and hub cap. Fit the gasket and fit the hub cap bolts and torque to 20-25Nm.





End float procedure Twin Bearing Hub

The twin bearing hubs have 2 equally sized tapered bearings on a straight spindle.

The correct method of setting end float is as follows:



- Slide hub/rotor assembly until fully home on the spindle.
- Fit lock washer 61305 to spindle locating it in the key of the spindle
- Fit the Lock Nut 61315 and tighten down by hand until contacting the lock washer.
- Torque spindle nut to a **375Nm**.
- Rotate the hub 4 full revolutions
- Then re torque the nut to 375Nm, this ensures the hub and the bearings are fully seated on the spindle.
- Now loosen the adjusting nut by one complete turn
- Finally torque the Lock Nut to 110Nm
- The locking screws go through the lock nut and in to the spindle lock washer. In order to achieve hole alignment with the lock washer it may be necessary to torque the spindle nut to greater than 110Nm. Always tighten, never loosen, to achieve hole alignment.
- Fit the M8 lock screws (61345) through nut and washer.
- Torque to **25Nm** using a 6mm hex key socket.



End float procedure Unipac Bearing Hub

The Unipac bearing is a pre-set enclosed bearing used on a straight spindle. To prevent the Unipac bearing seizing to the spindle ensure anti fretting paste is applied to the spindle shaft before placing the hub on to the spindle. Also ensure the snap ring holding the unipac bearing in the hub is fully seated.

- Slide hub/rotor assembly until fully home on the spindle.
- Fit lock washer 61305 to spindle locating it in the key of the spindle.
- Fit the spindle nut 61315 and tighten down by hand until contacting the lock washer.
- Torque the spindle nut to a **MINIMUM of 650 Nm.**
- The locking screws go through the lock nut and in to the spindle lock washer. In order to achieve hole alignment with the lock washer it may be necessary to torque the spindle nut to greater than 650Nm. Always tighten, never loosen, to achieve hole alignment.
- Fit the M8 lock screws (61345) through nut and washer.
- Torque to **25Nm** using a 6mm hex key socket, and small torque wrench.



Brakes

It is important that operators develop a schedule for periodic cleaning, inspection, adjustment and lubrication of brake components. This will provide the prevention rather than cure of brake problems.

Pads

The thickness of the pads must be checked regularly dependent on the usage of the vehicle. The pads should be checked corresponding to any legal requirements that may apply.

If no wear indicator has been connected, this should be at least every three months. If friction material is less than 2mm, the pads should be replaced.

Discs

The brake disc should be measured at the thinnest point. Avoid measuring near the edge of the disc as a burr may be present.

A = Disc thickness (new condition) 45mm.

B = Disc thickness (worn) 37mm, Disc must be replaced.


C = Overall thickness of Pad (new condition) 30mm

D = Backplate 9mm

E = Minimum thickness of friction material 2mm.

F = Minimum allowed thickness in worn condition for back plate and friction material 11mm. (replacement of Pads necessary).

If the disc thickness is less than 37mm, the disc must be replaced




For more details on Calliper Repairs refer to;


http://www.knorr-bremsecvs.com/en/activeservices/downloadservices/downloaddocumentation_1/downloaddocumentation_1.jsp

<http://inform.wabco-auto.com/intl/pdf/815/01/13/8150101133.pdf>

As part of the maintenance schedule, the disc should be checked for grooves and cracks.

See below possible conditions of the surface.





A1 -Small Cracks spread over the surface are allowed.

B1 -Cracks less than 1.5mm deep or wide, running in a Radial direction, are allowed.

C1 -Grooves (circumferential) less than 1.5mm wide are allowed.

D1 -Cracks in the vanes are NOT allowed and the Disc MUST BE REPLACED.


a = Pad Contact area

Note: In case of surface conditions A1 - C1, the Disc can continue to be used until the minimum thickness of 37mm is reached.

Granning Axles Discs are normally service free and grinding when changing Pads is not necessary. However, grinding could be useful, e.g. to increase the load-bearing surface of the pads after severe grooving on the entire friction surface has occurred. To meet safety requirements, the minimum thickness after regrinding is 39 -40 mm.

In addition, the recommendation of the vehicle manufacturer MUST be followed.

WARNING! If these recommendations are ignored , there is a danger of brake failure. If the Pads are worn down to the backplate or if the Disc wear is excessive, brake performance will be severely affected and may be lost completely.



Removal of Brake pads



First gain access to the brake pads by removing the wheel. Loosen the retaining bolt.




Lift away the retainer and bolt




Lift away spring retainers



Left out brake pads




Grease seal removal




It is acceptable to remove the grease seal with a screwdriver as long as great care is taken to avoid damaging the bearing and journal beneath it.

Once a grease seal has been removed, **NEVER** refit it as the seal will have been broken and will only be the cause of further problems.




When fitting a grease seal always take care as not to damage the seal or fitment. Granning advise the use of a grease seal driver, as this will help to correctly fit the grease seal.



Bearing removal





Outer bearing cone being removed.




Outer bearing cone being fitted

It is far more difficult to remove bearings from a shaft than to put them on. It is necessary to remove the bearings by using the correct tools, otherwise damage may be sustained to the balls/rollers or races. Since such damage is seldom visible, it does not become known until after complete reassembly. It is good preventative maintenance to replace most bearings during the overhaul period. If a bearing is not going to be replaced, avoid removal during low mileage rebuild.

With a unipac bearing assembly the snap ring must be removed before the bearing can be removed. The snap ring has a chamfered edge which allows a screw driver to fit under so it can be prized out of the hub groove.



Snap ring must be removed.




Before fitment remember to check that the bearing is fully pre-packed with grease. When fitting bearings it is essential to use proper tools that have been designed for the task. Using these tools will help to prevent damage to the bearing. Damaging a bearing on fitment could cause increased wear and premature failure. Ensure bearing cone and seal are fully seated in hub before reassembly.

ABS

If the ABS pole wheel is being replaced or fitted, 100 tooth (Part no. 61789), it is important that it is fully seated on the hub and it is perfectly parallel to the hub face otherwise it will create an ABS fault reading. If replacing or changing the ABS sensor ensure it is properly coated with the supplied anti fretting paste.

Anytime an ABS axle is serviced the axle should be tested with an ABS testing device when reassembled.




Trouble shooting

Important Procedure

When locating and correcting axle troubles, a systematic procedure should be followed.

Check Functioning Prior to Disassembly:

Many times the answer to the trouble is apparent when the unit is inspected prior to disassembly, but this evidence is often lost when parts are separated. If possible, check the unit prior to disassembly. Bear in mind that a careful inspection of the unit should be made as each disassembly step is performed.





Inspect Thoroughly During Disassembly:

It is important to examine all the parts when disassembling an axle to check for wear and damage. After the axle is disassembled, check the lubricant for foreign particles which often reveal sources of troubles that are overlooked during the disassembly.

Repair or Replace Defective Parts:

All pieces should be accurately examined because the broken parts are often just the result and not the cause of the trouble. All parts that are broken or worn and no longer meet specifications should be replaced with genuine NEW components.

Excessive Brake Drum Wear:

Possible Causes:

- a) Overheating through excessive braking
- b) Contaminated Brake linings

Grease or Oil Leaks:

Possible Causes:

- a) Incorrect assembly or damaged seal
- b) Seal lips distorted
- c) Damaged / worn hub cap gasket
- d) Hubometer stem leaks

Loose Wheels:


Possible Causes:

- a) Incorrect torque
- b) Worn Cones / bolts
- c) Mismatched wheels and fasteners
- d) Damaged rims
- e) Excessive paint on hub

Hubs Overheating:

Possible Causes:

- a) Bearing adjustment too tight
- b) Insufficient lubrication



www.granningaxles.ie

80259 REV C Oct 2020 Page | 25

Ireland

T. +353 (0) 45 897 553
F. +353 (0) 45 848 638

UK

T. +44 (0) 1925 817 689
F. +44 (0) 1925 817 153

NI

T. +44 (0) 2890 740 055
F. +44 (0) 2890 752 718

Poland

T. +48 (0) 29 753 1616
F. +48 (0) 29 753 1604

Brakes Binding or Dragging:

Possible Causes:

- a) Failed brake shoe return spring
- b) Badly worn bearings
- c) Incorrectly adjusted brakes

- d) Brakes not releasing properly
- e) Faulty valve in brake system
- f) Faulty trailer air coupling

Bearing Failure:

Possible Causes:


- a) Abrasive contamination
- b) Overheating due to lack of end float
- c) Forceable assembly
- d) Incorrect end float
- e) Damaged dust cover

Bearing Failures:

More than 90% of all bearing failures are caused by dirt, which is always abrasive. Dirt may enter the bearings during assembly of the unit, or be carried into the bearing by the lubricant while in service. Dirt may enter through seals, or even dirty containers used for the addition or change of lubricant.

Softer material such as dirt, dust etc., usually form abrasive paste or lapping compounds within the bearings themselves since the unit pressure between the balls/rollers and raceways makes a perfect pulveriser. The rolling motion tends to entrap and hold the abrasives. As the balls/rollers and raceways wear, the bearings become noisy. The lapping action tends to increase rapidly as the fine steel from the balls/rollers and raceway adds to the lapping material.

Hard, coarse material such as chips etc., may enter the bearings during assembly from the hammers, drifts, power chisels etc., or may be manufactured within the unit during service from raking teeth, etc. These chips produce small indentations in balls/rollers and races. Jamming of these hard particles between balls/rollers and races may cause the inner race to turn in the housing.





Corrosion:

Water, acid and corrosive materials formed by deterioration of lubricant, will produce a reddish-brown coating and small etched holes over outer and exposed surfaces of race. Corrosive oxides also act as a lapping agent.

Brinelling is caused by improper assembly or removal, usually hammering with off centre blows. Use tubes, preferably under a press or extractor.


Fatigue:

All bearings are subject to fatigue and must be replaced eventually. Operators experience will dictate mileage replacement of bearings showing only normal wear.

Shaft Fits:

Excessive looseness under load is very objectionable because it produces a creeping or slipping of the inner ring on the rotating shaft. This causes the surface metal of shafts to scrub or wear off.

When play or looseness even 0.0025 mm exists between the bearing and shaft, there is a very powerful force tending to rotate the inner race on the shaft.





Contact Information

For axle and suspension products: www.granningaxles.ie

For replacement parts: www.airsprings.com

Granning Axles Ltd

Naas Industrial Estate
Naas
Co. Kildare
Ireland

Phone: +353 (0) 45 897 553
Fax: +353 (0) 45 848 638

Granning UK Ltd

36-37 Melford Court
Hardwick Grange
Warrington
Cheshire WA1 4RZ
England

Phone: +44 (0) 1925 817 689
Fax: +44 (0) 1925 817 153

Granning Belfast


201 York Road
Belfast BT3 9BL
Northern Ireland

Phone: +44 (0) 2890 740 055
Fax: +44 (0) 2890 752 718

Granning Polska Sp. z o.o.

ul. Pułtuska 112A
07-200 Wyszków
woj. Mazowieckie
Polska

Phone: +48 (0) 29 753 1616
Fax: +48 (0) 29 753 1604



www.granningaxles.ie

80259 REV C Oct 2020 Page | 28

Ireland

T. +353 (0) 45 897 553
F. +353 (0) 45 848 638

UK

T. +44 (0) 1925 817 689
F. +44 (0) 1925 817 153

NI

T. +44 (0) 2890 740 055
F. +44 (0) 2890 752 718

Poland

T. +48 (0) 29 753 1616
F. +48 (0) 29 753 1604